



[www.greenLS.com](http://www.greenLS.com)

## **Installing MotorSilk™ Products**

**Please read the directions below *BEFORE* installing the MotorSilk™ Products**

### **Directions to install MotorSilk™ Engine Treatment:**

One 16oz engine treatment treats 5 quarts of crankcase capacity (a 1:10 ratio) which is the normal oil level for most cars and light duty trucks. Refer to your owner's manual to determine how many quarts of oil your vehicle holds. This product should be added when the engine is warm and after installation run the engine for at least 5 minutes.

Refer to your vehicles Owners Manual for opening the hood of your car or truck and locating the Engine Oil dip stick and oil filler location. Check your oil with the dip stick to avoid overfilling. The MotorSilk™ treatment is equivalent to ½ quart of oil. Remove the oil filler cap. (It is best to use a small funnel to install the treatment) Shake the MotorSilk™ Engine Treatment before opening. Once shaken, remove the lid and seal and pour the entire treatment into the oil intake through the funnel. Replace the oil filler lid and check to make sure the dip stick and oil filler lid are properly sealed.

### **Directions to install MotorSilk™ Automatic Transmission Treatment:**

One 10oz Automatic Transmission Treatment treats most cars and light truck transmissions. For larger transmissions add 10oz for every gallon of automatic transmission fluid specified.

Follow the Owners manual for opening the hood of your car or truck and locating the transmission fluid dip stick which also serves as the filler tube on most vehicles. (Note: DO NOT USE the MotorSilk™ Automatic Transmission Treatment in CVT transmissions (Continuous Variable Transmissions) or sealed transmissions. The owner's manual for your vehicle will tell you what type of transmission you have) Start your car making sure it is in park and the emergency brake is engaged. Check the transmission fluid level to avoid overfilling. Using caution around the running engine, remove the transmission dip stick. (It is best to use a small funnel to install the treatment) Shake the MotorSilk™ Automatic Transmission Treatment before opening. Once shaken, remove the lid and seal and pour the treatment into the transmission fluid intake through the funnel. Replace the transmission dip stick and check to make sure the dip stick is properly sealed.

### **Directions to install MotorSilk™ Manual Transmission Treatment (Gear Fluid):**

One 10oz Manual Transmission Treatment treats most differential/gearboxes. For larger gearboxes use 1 part Gear Fluid Treatment to 10 parts gear fluid.

We recommend the manual Gear Fluid Treatment be installed by a qualified mechanic.

### **Directions to install MotorSilk™ Gas Treatment:**

One 16oz MotorSilk™ Gas Treatment treats 18-22 gallons of gasoline.

Determine the size of your vehicles fuel capacity from the Owners manual. Remove the cap and seal from the bottle and carefully pour the MotorSilk™ Gas Treatment into your gas tank through the gas filler tube. Add the MotorSilk™ Gas Treatment when your vehicle has a full tank of gas.

### **Directions to install MotorSilk™ Diesel Treatment:**

One 16oz MotorSilk™ Diesel Treatment treats 125 gallons of diesel fuel.

Determine the size of your vehicles diesel fuel capacity from the Owners Manual. Remove the cap and seal from the bottle and carefully pour the MotorSilk™ Diesel Treatment into your vehicles diesel fuel filler tube to a full tank in the appropriate amount. For example, if your vehicle has a 30 gallon tank, you would add ¼ of the 16oz treatment each fill up for 4 fill ups.

***NOTE: If you are unable or uncomfortable installing the MotorSilk™ products, most auto repair or Oil change shops will install the product for you.***

## **Installing MotorSilk™ Products - Frequently Asked Questions**

### **Does MotorSilk™ work in all cars and trucks?**

The MotorSilk™ Engine Treatment can be used in any vehicle; however the product displaces carbon, grime, corrosion and sludge buildup on your engine's internal metal surfaces while bonding to provide the extreme reduction of friction. On high mileage vehicles of over 100,000 miles or vehicles that have not received the manufacturer's scheduled oil changes, that buildup will be deposited in your oil filter. We recommend that in high mileage vehicles of over 100,000 miles and vehicles that have not received proper maintenance, to have the oil tested for wear particles at a local Oil testing facility before installing the product. (Oil test facilities can be found on the internet) If you do experience unexpected behavior from your vehicle after installation and time for bonding, we recommend you replace the oil filter at once to remove the deposits in that filter.

### **When should I install MotorSilk™?**

We recommend installing MotorSilk™ Engine Treatment right after an oil change leaving the oil ½ quart low for the engine treatment fluid to avoid overfilling. It takes approximately 400 to 1000 miles for the product to bond to your engine. If you don't install MotorSilk™ Engine Treatment at a regular scheduled oil change, make sure when you do install it, you do not change your oil for at least 2000 miles to ensure proper bonding. After 2000 miles the product will remain in your vehicle, even after an oil change, and will continue to regenerate and be effective in your engine for up to 100,000 miles.

### **Does MotorSilk™ void any warranties?**

MotorSilk™ products exceed all manufacturers' engine warranty requirements and do not void any warranties.

### **What engines does MotorSilk™ work in?**

MotorSilk™ Engine Treatment will work in any type engine regardless of how many cylinders or whether it is a diesel or gas engine. The product line includes a 2 cycle product for those types of engines also.

### **Can MotorSilk™ be used in boats, lawn mowers, tractors, etc?**

MotorSilk™ will work in all engines including boat engines, tractors, generators, lawn mowers, etc. With its anti-corrosive benefits, it provides internal protections from rust in engines exposed to the elements or are not frequently in use. The MotorSilk™ line of products includes several finished products such as grease, hydraulic fluid and a pump spray that provide biodegradable, nontoxic and anti-corrosive benefits with every application.

### **What are the MotorSilk™ warranty and/or guarantee?**

There isn't a warranty or guarantee. Since there are so many variables once you add the product to your engine, we cannot guarantee specific results.

For additional information and to view our Installation Video, visit our website at: [www.greenLS.com](http://www.greenLS.com)